



# PROKOP

**Podnośniki PROKOP Ewelina Prokop**

ul. Dworcowa 20c/8, 58-560 Jelenia Góra


tel./fax: +48 507 033 123

www.podnosnikiprokop.pl | podnosnikiprokop@onet.pl

**100t**

## LIEBHERR LTM 1100

**Wymiary  
Maße  
Dimensions**



R<sub>i</sub> = Allradlenkung · All wheel steering

Wymiary · Maße · Dimensions

	A	B	C	D	E	F	G	H	I
14.00 R 25	3950	2313	2750	3667	1890	16°	12°	19°	13°
16.00 R 25	4000	2301	2750	3717	1940	18°	14°	21°	15°
20.5 R 25	4000	2363	2890	3717	1940	18°	17°	21°	15°